

# Combination Microwave Instruction Manual

## **CM121BK**



## CONTENTS

Warnings	3
Environmental Protection	10
Warranty	10
Cleaning	12
Utensils	12
Setting up your Microwave	15
Installation	16
Operation Instructions	21
Troubleshooting	29
Technical Data	30
Caple Contact Details	32

## SAFETY INSTRUCTIONS

Read carefully all the instructions contained in this manual. It provides you with important information regarding the safe installation, use and maintenance of the appliance as well as useful advice for getting the best out of your microwave oven. Keep this booklet in a safe place for future reference. After removing the packing, check that the appliance is not damaged in any way.

Be careful not to leave the packing materials (plastic sheeting, expanded polystyrene etc.) where children can get at them, as they can be dangerous.

## IMPORTANT:

Do not use the oven door handle to move the appliance, such as to remove it from the packaging.

## ATTENTION:

The microwave oven is an appliance which, for its nature, becomes hot during use, especially the glass door.

It is therefore a good rule that children do not approach the microwave oven when it is functioning, particularly when the grill is in use.

Never roast or bake on the oven base.

This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments.
- Farm Houses.
- By clients in hotels, motels and other residential type environments.
- Bed and breakfast type environments.

The electrical system of this appliance may be used safely only when it is correctly connected to an efficient earthing system in compliance with the safety standards currently in effect.

The manufacturer will not be held liable for any damages that might arise out of incorrect or improper use of the appliance.

The following items are potentially dangerous, and therefore, appropriate measures must be taken to prevent children and the disabled from coming into contact with them:

- Controls and the appliance in general
- Packaging (bags, polystyrene, nails, etc.)
- The appliance immediately after use of the oven or grill due to the heat generated.
- The appliance when no longer in use (potentially dangerous parts must be made safe).

## WARNING:

Accessible parts will become hot when in use. To avoid burns and scalds children should be kept away.

During use the appliance becomes hot, Care should be taken to avoid touching heating elements inside the oven.

- If the door or door seals are damaged, the oven must not be operated until it has been repaired by a Caple approved engineer.
- It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
- Liquids and other foods must not be heated in sealed containers since they are liable to explode.
- Only use utensils that are suitable for use in microwave ovens.
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
- The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
- The oven should be cleaned regularly and any food deposits removed
- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

## WARNING:

To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

- Make sure that all the packing materials are removed from the inside of the door.

## WARNING:

- Check the oven for any damage, such as misaligned or bent door, damaged door seals and sealing surface, broken or loose door hinges and latches and dents inside the cavity or on the door. If there is any damage, do not operate the oven and contact Caple service immediately.
- This microwave oven must be placed on a flat, stable surface to hold its weight and the heaviest food likely to be cooked in the oven.
- Do not place the microwave oven where heat, moisture, or high humidity are generated, or near combustible materials.
- Do not operate the microwave oven when empty.
- Do not operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been damaged or dropped. If the supply cord is damaged, it must be replaced by Caple or an approved engineer in order to avoid a hazard.
- Microwave heating of liquids can result in delayed eruptive boiling, therefore care has to be taken when handling the container.
- Do not fry food in the microwave oven. Hot oil can

damage oven parts and utensils and even result in skin hirrns

- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode even after microwave heating has ended.
- Pierce foods with heavy skins such as potatoes, whole squashes, apples and chestnuts before cooking.
- The contents of feeding bottles and baby jars should be stirred or shaken and the temperature should be checked before serving in order to avoid burns.
- Utensils should be checked to ensure that they are suitable for use in microwave oven.

## WARNING:

Liquid or other food must not be heated in sealed containers since they are liable to explode.

## WARNING:

It is hazardous for anyone other a trained person to carry out any service or repair operation which involves the removal of any cover which gives protection against exposure to microwave energy.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless the have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- When heating food in plastic or paper containers, check the oven frequently for the possibility of ignition.
- Remove wire ties from paper or plastic bags before placing bag in oven.
- If smoke is observed. Switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- Do not leave paper products, cooking utensils or food in the cavity when not in use.

## WARNING:

The appliance and its accessible parts become hot during use.

Care should be taken to avoid touching heating elements.

Children less than 8 years of age shall be kept away unless continuously supervised.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.

Electric shock hazard: Touching some of the internal

components can cause serious personal injury or death. Do not disassemble this appliance.

Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or appliance engineer if the grounding instructions are not completely understood or in doubt as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord.

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.

If a long cord set or extension cord is used:

The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.

The extension cord must be a grounding-type 3-wire cord. The long cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.



#### **ENVIRONMENTAL PROTECTION**

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. This appliance is marked according to the European Directive on Waste Electrical and Electronic Equipment (WEEE).

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The symbol on the product indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery and recycling of this product, please contact your local council, your household waste disposal service or the retailer where you purchased the product.

## CE DECLARATIONS OF CONFORMITY

This appliance has been manufactured to the strictest standards and complies with all applicable legislation, Low Voltage Directive (LVD) and Electromagnetic Compatibility (EMC).

## UKCA DECLARATIONS OF CONFORMITY

This appliance has been manufactured to the strictest standards and complies with all applicable legislation.

#### WARRANTY:

Your new appliance is covered by warranty. The warranty card is enclosed - if it is missing, you must provide the following information to your retailer in order to receive a replacement: date of purchase, model and serial number (placed on the inside of the appliance storage drawer). Registration can also be completed online by visiting www.caple.co.uk.

Ensure you keep your warranty card safe, you may need to show it to Caple Service together with proof of purchase.

If you fail to show your warranty card you will incur all repair charges.

Spare parts are only available from Caple Service and spare parts authorised centres.

#### ATTENTION:

- > Before use, remove all plastic films protecting some parts of the appliance (fascia panel, parts in stainless steel, etc.)
- > Do not use the appliance to heat a room.
- > When the appliance is not in use, we recommend you turn it off, isolate it from the electrical supply.

#### CIFANING

Be sure to unplug the appliance from the power supply before any cleaning.

- 1. Clean the cavity of the oven after using with a slightly damp cloth.
- 2. Clean the accessories in the usual way in soapy water.
- 3. The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
- 4. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

#### **CLEANING TIP:**

For easier cleaning of the cavity walls: Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% microwave power for 10 minutes. Wipe the oven clean using a soft, dry cloth.

#### UTENSILS

#### WARNING:

Personal Injury Hazard: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

#### IITENSII TEST.

- > Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
- > Cook on maximum power for 1 minute.
- > Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
- > Do not exceed 1 minute cooking time.

## MATERIALS YOU CAN USE IN A MICROWAVE OVEN:

UTENSILS	REMARKS	
BROWNING DISH	Follow manufacturer's instructions. The bottom of the browning dish must be at least 5mm above the turntable. Incorrect usage may cause the turntable to break.	
DINNERWARE	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.	
GLASS JAR	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.	
GLASSWARE	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.	
OVEN COOKING BAGS	Follow manufacturer's instructions. Do not close with a metal tie. Make slits to allow steam to escape.	
PAPER PLATES AND CUPS	Use for short—term cooking/warming only. Do not leave oven unattended while cooking.	
PAPER TOWELS	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.	
PARCHMENT PAPER	Use as a cover to prevent splattering or a wrap for steaming.	
PLASTIC	Microwave-safe only. Follow the manufacturer's instructions. Should be labelled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.	
PLASTIC WRAP	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.	
THERMOMETERS	Microwave-safe only (meat and candy thermometers).	
WAX PAPER	Use as a cover to prevent splattering and retain moisture.	

#### MATERIALS TO BE AVOIDED IN A MICROWAVE OVEN:


UTENSILS	REMARKS	
ALUMINIUM TRAY	May cause arcing. Transfer food into microwave-safe dish.	
FOOD CARTON WITH METAL HANDLE	May cause arcing. Transfer food into microwave-safe dish.	
METAL OR METAL- TRIMMED UTENSILS	Metal shields the food from microwave energy. Metal trim may cause arcing.	
METAL TWIST TIES	May cause arcing and could cause a fire in the oven.	
PAPER BAGS	May cause a fire in the oven.	
PLASTIC FOAM	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature	
WOOD	Wood will dry out when used in the microwave oven and may split or crack.	

## SETTING UP YOUR MICROWAVE

#### PARTS AND ACCESSORIES:

Remove the appliance and all materials from the carton and appliance cavity. Your appliance comes supplied with the following accessories:

CONTENTS	QUANTITY
Glass Turntable	1
Turntable Ring Assembly	1
Instruction Mw anual	1



- A. Control panel
- B. Turntable shaft
- C. Turntable ring assembly
- D. Glass turntable

F. Observation window

Α

- F. Door assembly
- G. Safety interlock system



## GRILL RACK

(Only to be used in the grill function and to be placed on the glass turntable)

#### INSTALLATION

#### TURNTABLE INSTALLATION

- > Never place the glass tray upside down. The glass tray should never be restricted.
- > Both the glass tray and turntable ring assembly must always be used during cooking.
- > All food and containers of food must always be placed on the glass turntable for cooking.
- > If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorised Caple Service centre.



#### INSTALLATION AND CONNECTION

- > This appliance is only intended for domestic use. The guarantee is void if used in any commercial application.
- > This oven is intended for built-in use only. It is not intended for counter-top use or for use inside a cupboard.
- > Please observe the detailed installation instructions.
- > The appliance can be installed in a 60cm wide wall-mounted cupboard (at least 55cm deep and 85cm off the floor).
- > The appliance is fitted with a plug and must only be connected to a properly installed earthed socket.
- > The mains voltage must correspond to the voltage specified on the rating plate.
- > The socket must be installed and the connecting cable must only be replaced by a qualified electrician. If the plug is no longer accessible following installation, an all-pole disconnecting device must be present on the installation side with a contact gap of at lease 3mm.
- > Adapters, multi-way strips and extension leads must not be used. Overloading can result in a risk of fire.

#### WARNING:

The accessible surface may be hot during operation.




#### **ELECTRICAL CONNECTION:** NOTF:

The microwave oven is fitted with a plug and must only be connected to a properly installed earthed socket. The socket must only be installed and the connecting cable must only be replaced by a qualified electrician, and in accordance with the appropriate regulations.

If the plug is not longer accessible following installation, an all-pole isolating switch must be present on the installation side with a contact gap of at least 3mm.

#### WARNING.

Do not trap or bend power cable.



#### **BUILT IN FURNITURE**

#### NOTE:

The fitted cabinet the appliance is being installed into must not have a back wall behind the appliance. A gap must be maintained between a wall and the base of the unit above. Specific gap size can be referenced by the diagrams.


Minimum installation height: 85cm


#### NOTE:

Do not trap or bend the power cable.

#### **WARNING:**


Do not cover a ventilation slot or air intake points.






All dimensions are shown in mm

#### INSTALLING THE MICROWAVE



Fix adjustable screw A located on the upper air tunnel of the microwave, and then install the microwave into the cabinet.


- Adjust the height of adjustable screw A to keep 1mm gap between the screw A and the top plane of cabinet.
- > Take care not to trap or kink the power cord.
- Make sure the microwave oven is installed in the centre of the cabinet.



Open the door and fix the microwave to the cabinet with screw B through the installation hole of the trim kit. Then push the plastic cover in to the installation hole to cover the fixing.

### OPERATION INSTRUCTIONS

#### **DISPLAY SCREEN:**



- 1. Microwave
- 2. Grill
- 3. Defrost by time
- 4. Defrost by weight
- 5. Cooking
- 6. Hours/mins/secs
- 7. Clock
- 8. Cooking timer
- 9. Auto menu cooking
- 10. Child safety lock
- 11. Weight

#### SETTING THE CLOCK:

When the microwave oven is switched on, the LED will display "0:00", the buzzer will ring once.

- > Press "Kitchen Timer/Clock" twice to select clock function, the hour figures will flash.
- > Turn " 💜 " to adjust the hour figures, the input item should be within 0-23hr.
- > Press "Kitchen Timer/Clock" the minute figures will flash.
- > Turn " "" to adjust the minute figures, the input time should be within 0-59.
- > Press "Kitchen Timer/Clock" to finish setting the clock. ":"will flash, and the time will illuminate.

#### NOTE:

If the clock is not set, only quick start will be able to be used. Set the clock to allow all programmes to be used.

During the process of setting the clock, if you press "Stop/Clear" the oven will go back to the previous status automatically.

#### MICROWAVE COOKING:

Press "Microwave" the LED will display "P100".Press "Microwave" a few times or turn " to choose the power you want, and "P100", "P80" "P50", "P30" or "P10" will display for each added press. Then press "Start/+30Sec/Confirm" to confirm, and turn " ?" to set the cooking time from 0:05 to 95:00. Press "Start/+30Sec/Confirm" again to start cooking.

#### **EXAMPLE:**

If you want to use 80% microwave power to cook for 20 minutes, you can operate the appliance as the following steps.

- > Press "Microwave" once, the screen display "P100".
- > Press "Microwave" once again or turn" ? " to choose 80% microwave power.
- > Press "Start/+30Sec/Confirm" to confirm, and the screen displays "P80".
- > Turn "  $\P$ " " to adjust the cooking time until the oven displays "20:00".
- > Press "Start/+30Sec/Confirm" to start cooking.

#### NOTE:

When selecting a cooking duration, the timer will increase in the following quantities:

0 - 1 minute	5 seconds
1 - 5 minutes	10 seconds
5 - 10 minutes	30 seconds
10 - 30 minutes	1 minute
30 - 95 minutes	5 minutes

## For example:

When selecting a cooking duration between 1-5 minutes the timer will go up in 10 second increments.

MICROWAVE	PAD INSTRUCTIONS DISPLAY	MICROWAVE POWER
1	P100	100%
2	P80	80%
3	P50	50%
4	P30	30%
5	P10	10%

GRILL/COMBI	PAD INSTRUCTIONS DISPLAY	MICROWAVE POWER	GRILL POWER
6	G	0%	100%
7	C - 1	55%	45%
8	C - 2	36%	64%

#### COMBINATION COOKING:

Press "Grill/Combi" the LED will display "G" and press "Grill/Combi" a few times, "C-1" or "C-2" will display for each added press. Then press "Start/+30Sec/Confirm" to confirm and turn " 🔍 " to set cooking time from 0:05 to 95:00.

Press "Start/+30Sec/Confirm" again to start cooking.

#### **EXAMPLE:**

If you want to use 55% microwave power and 45% grill power (C-1) to cook for 10 minutes, you can operate the oven as the following steps.

- > Press "Grill/Combi" once, the screen display "G".
- > Press "Grill/Combi" a few times or turn " ?" to choose combi 1 mode.
- > Press "Start/+30Sec/Confirm" to confirm, and the screen displays "C-1".
- > Turn " " to adjust the cooking time until the oven displays "10:00".
- > Press "Start/+30Sec/Confirm" to start cooking .

#### NOTE:

If half the grilling time passes and the oven sounds twice, this is normal. In order to have a better effect when grilling food, you should turn the food over, close the door, and then press

"START/ +30SEC./ Confirm" to continue cooking.

If there is no operation, the oven will continue cooking.

#### **QUICK START:**

- > In standby mode, press "Start/+30Sec/Confirm" to start cooking with 100% power, each added press will increase 30 seconds cooking time up to 95 minutes.
- > In microwave, grill cooking or time defrost state, each press of "Start/+30Sec/Confirm" can increase 30 seconds of cooking time.
- > In standby mode, turn " () " anticlockwise to set cooking time with 100% microwave power, then press "Start/+30Sec/Confirm" to start cooking.

#### **DEFROST BY WEIGHT:**

- > Press "Weight/Time Defrost" once, and the oven will display "dEF1".
- Turn " to select the weight of food from 100 to 2000g.
- > Press "Start/+30Sec/Confirm" to start defrosting.

#### **DEFROST BY TIME:**

- > Press "Weight/Time Defrost" twice, and the oven will display "dEF2".
- > Turn " ?" " to select the defrost time. The MAX time is 95 minutes.
- > Press "Start/+30Sec/Confirm" to start defrosting. The defrost power is P30, this cannot be changed.

#### KITCHEN TIMER:

- > Press "Kitchen/Timer/Clock" once, LED will display 00:00.
- > Turn " " to enter the correct timer. (The maximum cooking time is 95 minutes).
- > Press "Start/+30Sec/Confirm" to confirm setting.
- > When the kitchen time is reached, the clock indicator will go out and the buzzer will ring 5 times. If the clock is set (24-hour system), the LED will display the current time.

#### NOTE:

The kitchen timer is different from the 24-hour system, the kitchen timer is a timer only.

#### AUTO MENU:

- > Turn " clockwise to choose the menu, and "A-1" to "A-8" will display pizza, meat, vegetable, pasta, potato, fish, beverage and popcorn.
- > Press "Start/+30Sec/Confirm" to confirm.
- > Turn " " to choose the default weight as the menu chart.
- > Press "Start/+30Sec/Confirm" to start cooking.

#### Example:

If you want to use "Auto Menu" to cook 350g of fish.

- > Turn " clockwise till "A-6" display.
- > Press "Start/+30Sec/Confirm" to confirm.
- > Turn " " to select the weight of fish till "350" display.
- > Press "Start/+30Sec/Confirm" to start cooking.

#### THE AUTOMATIC MENU CHART:

MENU	WEIGHT	DISPLAY
A-1	200g	200
PIZZA	400g	400
	250g	250
A-2 MEAT	350g	350
	450g	450
	200g	200
A-3 VEGETABLES	300g	300
	400g	400
A-4	50g (with 450ml cold water)	50
PASTA	100g (with 800ml cold water)	100
	200g	200
A-5 POTATO	400g	400
	600g	600

MENU	WEIGHT	DISPLAY
	250g	250
A-6 FISH	350g	350
	450g	450
A-7 BEVERAGE	1 cup (120ml)	1
	2 cups (240ml)	2
	3 cups (360ml)	3
A-8 POPCORN	50g	50
	100g	100

#### MULTI STAGE COOKING:

Two cooking stages can be set. If one stage is defrosting, it should be put in the first stage. The buzzer will ring once after each stage and the next stage will begin.

#### NOTE:

Auto menu and preheating cannot be set as one of the multi stage options.

#### **EXAMPLE:**

If you want to defrost food for 5 minutes and then cook with 80% microwave power for 7 minutes, operate it as the following:

- > Press "Weight/Time Defrost" twice, and the oven will display "dEF2".
- > Turn " " to select the defrost time till "5:00" display.
- > Press "Microwave" once, the screen display "P100".
- > Press "Microwave" once again or turn " or to choose 80% microwave power.
- > Press "Start/+30Sec/Confirm" to confirm, and the screen displays "P 80".
- > Turn " " to adjust the cooking time till the oven displays "7:00".
- > Press "Start/+30Sec/Confirm" to start cooking, the buzzer will sound once for the first section and the defrosting time starts to count down. The buzzer will sound once again entering the second section of cooking. When cooking finishes the buzzer sounds five times.

#### INQUIRING FUNCTION:

- > In microwave, grill and combination cooking state, press "Microwave" or "Grill/Combi" and the current power will be displayed for 3 seconds. After 3 seconds, the oven will revert back to the former state.
- > If the clock has been set, press "Kitchen/Timer/Clock" to inquire the time and the time will display for 3 seconds.

#### CHILD SAFETY LOCK:

#### LOCK:

In standby state, press "Stop/Clear" for 3 seconds, there will be a "beep" denoting entering the child lock sate. — Will light and current time will display if the time has been set. Otherwise the screen will display [ ] ].

#### UNLOCK:

In locked state, press "Stop/Clear" for 3 seconds, there will be a "beep" denoting that the lock is released.

## TROUBLESHOOTING

NORMAL		
Microwave oven interring with TV reception.  Radio and TV reception may be interfered when microwave is operating. It similar to the interference of small electrical appliances like, mixer, vacuum, clean and electric fan. It is normal.		
Dim microwave light.	In low power microwave cooking, microwave light may become dim. It is normal.	
Steam accumulating on door, hot air out of vents.	In cooking, steam may come out of food, most will get out form vents but some may accumulate on a cool place such as the microwave door. It is normal.	
Microwave started accidentally with no food in.	You must not run the unit without any food inside. It is very dangerous.	

TROUBLE	POSSIBLE CAUSE	REMEDY
	Power cord not plugged in tightly.	Unplug. Then plug again after 10 seconds.
Microwave can not be started.	Fuse blowing or circuit breaker works.	Replace fuse of reset circuit breaker (repaired by professional personnel of our company).
	Trouble with outlet.	Test outlet with other electrical appliances.
Microwave does not heat.	Door not closed well.	Close door well.
Glass turntable makes a noise when microwave operates.	Dirty roller rest microwave bottom.	Refer to "Maintenance of Microwave" to clean dirty parts.

## TECHNICAL DATA

MODEL	CM121BK
RATED VOLTAGE:	230-240V ~ 50Hz
RATED INPUT POWER (MICROWAVE)	1100W
RATED OUTPUT POWER (MICROWAVE)	700W
RATED INPUT POWER (GRILL)	1000W
OVEN CAPACITY	17L
TURNTABLE DIAMETER	245mm
EXTERNAL DIMENSIONS	382x595x320mm

**NOTES:** 



Caple Service Fourth Way

Avonmouth T: 0117 938 1900

Bristol E: service@caple.co.uk

BS11 8DW www.caple.co.uk