

Filtro safelock filter information

How do I change my Filtro Safelock filter?

Each replacement cartridge comes with complete instructions on replacing your filter and should take less than 5 minutes, The advice below is a summary of the 4 simple steps.



1) Turn off the water to the filter & run the tap until empty.



2) Twist the filter 90° then pull



3) Push then twist the filter 90°



4) Turn on the water to the filter

How does the Filtro filter perform compared to other brands?

This is mainly a subjective matter and relies on the person and the original quality of water available; subsequently we feel it is not fair to offer such comparisons.

The following information is available on our Filtro filter system however:

- **Triple stage filter:**
 Stage 1 - cellulose fibre sediment filter – this pre- filter become progressively finer trapping more and more dirt & sediment and helps to prevent accidental blockage.
 Stage 2 - Granular activated carbon (GAC) – removes unwanted tastes, odours & chlorine
 Stage 3 – Scale crystals – treats the water reducing the effects of ‘hard water’
- **Minimum & Maximum water pressure rating (filter only) 1.8 - 5.5 bar**
- **5 micron rated filter, note a human hair is apx. 70 microns wide.**
- **5,678 Litres or 6 months maximum cartridge life**